

CLUBSWAN 36

Notice #05/2020

Aft Guardrail

An aft guardrail shall be installed across the transom at all times whilst racing, attached between the top of the aft stanchions.

Downwind Jib Sheet

A downwind jib sheet may be installed with blocks lashed to the deck padeye by the chainplates (Item 31) and/or Jibsheet fairlead (Item 27).

Teams are encouraged to share systems that work to develop a standard system that works which will be documented in the Class Rules.

Jibsheet Fairlead
(Item 27)

Padeye
(item 31)



Andrew Yates
ClubSwan 36 Class Measurer
08 September 2020